


TFE EVO vs TFE TEAM EDITION

HOW TO CHOOSE


With the hand holding an extension or a tube at 45°, measure from tip of elbow to where the top of the hand grips the extension. This forearm length measurement will provide a general guide for suggested aerobar length. If you are at the bottom of a size range or have larger forearms, Vision recommends sizing down one size. Arm shape/size, wrist flexibility and individual stack, reach, angle and width dimensions may change your individual extension length choice. As individual needs may vary, Vision also recommends working with a qualified bike fitter to properly determine correct extension length.




☐ Metron TFE EVO size :

MEASURE A	SIZE
≤ 370mm	<input type="checkbox"/> XS
From 365 to 390mm	<input type="checkbox"/> S
From 385 to 410mm	<input type="checkbox"/> M
≥ 405mm	<input type="checkbox"/> L


XS




S



M




L




☐ Metron TFE Team Edition size :

MEASURE A	SIZE
≤ 375mm	<input type="checkbox"/> S
From 370 to 405mm	<input type="checkbox"/> M
≥ 400mm	<input type="checkbox"/> L

S



M



L

